


SMART Board™ Start Center

You are only one press away from the most frequently used SMART Board features and applications with the Start Center.

Opening the Start Center

It's easy to open the Start Center. Press the SMART Board icon  in the Microsoft® Windows® Notification Area at the bottom right of your screen and select **Start Center** from the menu.




Notification Area

NOTE: The Start Center is only available when you are working on a SMART Board interactive whiteboard or Symposium™ product.

What Do the Buttons Do?

There are eight buttons on the default Start Center toolbar. Seven of the buttons are set to launch commonly used applications. The More button allows you to customize the Start Center to do what works best for you.



Customizing the Start Center

Add tools or applications to the Start Center to make working at your SMART Board interactive whiteboard even easier. To customize your Start Center press the **More** button and select **Customize Start Center**.

The diagram illustrates the 'Customize Start Center' dialog box and its interaction with the Start Center toolbar. The toolbar on the left contains icons for various tools, with a 'More' button (a question mark icon) at the bottom. Clicking the 'More' button opens a menu with 'Customize Start Center...' selected. The 'Customize Start Center' dialog box is divided into two main sections: 'Available Tools' and 'Current Toolbar'. The 'Available Tools' section lists Calculator, Magnifier, Pointer Tool, Screen Shade, and Spotlight. The 'Current Toolbar' section lists Notebook, Recorder, Video Player, Keyboard, Floating Tools, Control Panel, and Help. Between these sections are 'Add >>', '<< Remove', and 'Browse...' buttons. To the right of the 'Current Toolbar' are 'Move Up' and 'Move Down' buttons. At the bottom of the dialog are 'Restore Defaults', 'Customize View...', 'OK', and 'Cancel' buttons. Arrows point from text descriptions to each of these elements.

*Press **Add** to move a selected Available Tool to the Current Toolbar*

*Press **Remove** to take a tool off the Current Toolbar*

Change the order of the Current Toolbar

Select a tool

More Button

Customize Start Center...

Restore Defaults

Customize View...

OK

Cancel

Press to restore Start Center to the original configuration

Press to change the Start Center icon size and the transparency of the toolbar

Press to find and add an application not listed in Available Tools

Press to accept changes

Press to reject changes